


ELENCO PEZZI DI RICAMBIO
 LISTE PIECES DETACHEES
 SPARE PARTS LIST
 ERSATZTEILLISTE
 PIEZAS DE REPUESTO

DYNAMIC 320 START
DYNAMIC 420 START




Esploro macchina, Dessin appareil, Machine drawing, Explosions Zeichnung des Geräts, Diseño seccionado maquina.




REF.	ELENCO PEZZI DI RICAMBIO PIECES DETACHEES SPARE PARTS LIST ERSATZTEILLISTE PIEZAS DE REPUESTO	DYNAMIC	DYNAMIC
		320 START	420 START
		CODICE	CODE
1	Protezione Raddrizzatore Protection Redresseur Rectifier Protection Gleichrichterschutz Proteccion Rectificador	112185	112183
2	Termostato Thermostat Thermostat Thermostat Termostato	122308	121021
3	Interruttore Interrupteur Switch Schalter Interruptor	122477	122381
4	Deviatore Gareur Switch Schalter Interruptor	122400	122400
5	Termostato Thermostat Thermostat Thermostat Termostato	121069	122900
6	Cavo 16Mmq 2M- Massa Cable 16Mmq 2M- Masse Cable 16Mmq 2M- Earth Kabel 16Mmq 2M- Masse Cable 16Mmq 2M- Mase	980365	980366
7	Cavo Alim. 3G2.5 2 M Spina Schuko Cable Alim. 3G2.5 2 M Fiche Schuko Mains Cable 3G2.5 2 M Schuko Plug Netzkabel 3G2.5 2 M Schuko Stecker Cable Alim. 3G2.5 2 M Espina Schuko	132310	132009
8	Amperometro Amperemtre Ammeter Amperemeter Amperimetro	152020	152248
9	Trasformatore Transformateur Transformer Transformator Transformador	169539	169331
10	Volantino Volant Handwheel Handrad Volante	312053	312053
11	Manico Poignee Handle Handgriff Manija	312408	312408
12	Cuffia Per Fusibili Couvre Fusibles Fuse Cover Kasten Fuer Sicherungen Cubrefusible	322051	322051
13	Pressacavo Presse Cable Cable Bushing Kabelhalter Prensa Cable	322112	322112
14	Ruota Roue Wheel Rad Rueda	322193	322193
15	Tappo Blocca Ruota Bouchon Ferme Roue Wheel Locking Ring Radsperrestopfen Tapon De Bloqueo Rueda	322223	322223
16	Frontale Partie Frontal Front Panel Geraetefront Frontal	322801	322801

REF.	ELENCO PEZZI DI RICAMBIO PIECES DETACHEES SPARE PARTS LIST ERSATZTEILLISTE PIEZAS DE REPUESTO	DYNAMIC	DYNAMIC
		320 START	420 START
		CODICE	CODE
17	Piedino Embout Foot Fuss Pie	322803	322803
18	Cornice Cadre Frame Rahmen Marco	322804	322804
19	Tasca Poche Pocket Tasche Bolsillo	362001	362002
20	Asse Per Ruote Axes Pour Roue Wheels Axle Raederachse Eje Por Rueda	422961	422961
21	Fondalino Chassis Bottom Boden Fondo	644177	644177
22	Kit Cruschetto Kit Tableau Dashboard Kit Schaltbrett Kit Kit Cuadro	981254	980353
23	Colorado 150B Pinza Di Massa 150A Colorado 150B Pince De Masse 150A Colorado 150B Work Clamp 150A Colorado 150B Masseklemme 150A Colorado 150B Pinza De Masa 150A	712001	712001
24	Colorado 150R Pinza Positivo 150A Colorado 150R Pince Positiv 150A Colorado 150R Positive Clamp 150A Colorado 150R Positive Zange 150A Colorado 150R Pinza Positivo 150A	712002	712002
25	Kit 20 Fusibili 80A Kit 20 Fusibles 80A Kit 20 Fuses 80A Kit 20 Flachsicherungen 80A Kit 20 Fusibles 80A	802259	802260
26	Morsetto Per Fusibile Borne Pour Fusible Fuse Holder Sicherungshalter Bocadillo Para Fusible	980036	980036
27	Kit Retro Kit Partie Arriere Back Panel Kit Rueckseite Kit Kit Trasera	980301	980301
28	Kit Raddrizzatore Kit Redresseur Rectifier Kit Gleichrichter Kit Kit Rectificador	990685	980303
29	Kit Morsetto Completo D.33mm Kit Borne Complete D.33mm Complete Terminal Kit D.33mm Komplet Kabelklemme Kit D.33mm Kit Borne Completo D.33mm	990162	990162
30	Kit Coppia Rondelle Isolanti Kit Rondelles Isolantes Insulating Washers Kit Isolierscheibekit Kit Arandelas Asladoras	990163	990163
31	Cavo 16Mmq 2M- Positivo Cable 16Mmq 2M- Positive Kabel 16Mmq 2M- Positive Cable 16Mmq 2M- Positivo	980317	980318

Schema elettrico, Schéma électrique, Diagram, Schaltplan, Esquema de conexiones.



DYNAMIC 320 START



DYNAMIC 420 START